


Installing the CCD Adapter to Use the 2.7" or 4" Field Flatteners with a CCD Camera

The field flattener for the 4" focuser and the CCD adapter, part # A1261, are shown in these illustrations. The same procedures apply to all 2.7" field flatteners shipped after May 1994 and CCD adapters A1260 and A1262.



Remove the bayonet ring of the field flattener. Place the CCD adapter against the machined surface on the field flattener assembly. Thread the bayonet ring back in place, which secures the CCD adapter. The 2" adapter (ADA2003 or ADA200) will thread onto the part of the CCD adapter that extends beyond the bayonet ring. Insert your CCD camera with its 2" nosepiece (either our AP16T or nosepiece that you already have.) and you are ready to image.

